

AOW Series



AIR HEATING (COOLING) UNIT WITH WATER-TO-AIR HEAT EXCHANGER



CONTENT

Safety requirements	3
Introduction	5
Use	5
Delivery set	5
Designation key	5
Technical data	5
Design and operating logic	7
Mounting and set-up	8
Connection to power mains	10
Connection to power mains	10
Maintenance	11
Troubleshooting	11
Storage and transportation rules	11
Manufacturer's warranty	12
Acceptance certificate	13
Seller's information	13
Mounting certificate	13
Warranty card	14









SAFETY REQUIREMENTS

- Read the user's manual carefully prior to the operation and installation of the unit.
- Installation and operation of the unit shall be performed in accordance with the present user's manual as well as the provisions of all the applicable local and national construction, electrical and technical codes and standards.
- The warnings contained in the user's manual must be considered most seriously since they contain vital personal safety information.
- Failure to follow the safety regulations may result in an injury or unit damage.
- Read the manual carefully and keep it as long as you use the unit.
- While transferring the unit control the user's manual must be turned over to the receiving operator.











Symbol legend used in the manual:

	WARNING!
	DO NOT!

UNIT MOUNTING SAFETY PRECAUTIONS

	The unit must be disconnected from the power supply prior to every installation or repair operation.		The unit must not be operated outside the temperature range stated in the user's manual or in aggressive or explosive environments.
	Do not install heating equipment or any other equipment close to the unit cable.		Do not use damaged equipment or conductors to connect the unit to power mains.
	While installing the unit follow the safety regulations specific to the use of electric tools.		Unpack the unit with care.
	Do not change the power cord length at your own discretion. Do not bend the power cord. Avoid damaging the power cord.		Use the unit as intended only.

UNIT OPERATION SAFETY PRECAUTIONS

	Do not carry out the unit maintenance with wet hands.		Do not wash the unit with water. Protect the unit electric parts from water ingress.
	Do not block the air intake and exhaust vents during the unit operation.		Disconnect the unit from power supply prior to maintenance.
	Do not let children operate the unit.		Do not damage the power cable while operating the unit. Do not put any objects on the power cable.
	Keep combustible gases and inflammable products away of the unit.		Do not open the operating unit.
	In case of unusual sounds, smoke disconnect the unit from power supply and contact the service centre.		Do not let air flow from the unit be directed to the open flame devices or candles.

INTRODUCTION

This user's manual includes technical description, operation, installation and mounting guidelines, technical data for the air heating (cooling) unit with water-to-air heat exchanger AOW, hereinafter referred as the unit.

USE

The air heating (cooling) units with water-to-air heat exchanger are designed for indoor air heating with the water-to-air heat exchanger and uniform air distribution with the fan and louvre shutters. The integrated high-efficient electric heater and a powerful fan enable quick air heating (cooling) in large premises or a local heating or cooling of a working space in hangars or industrial facilities.

The AOW unit is designed for air heating or cooling large industrial premises. Further application areas include workshops, garages, car showrooms, stock houses, trade facilities, super- and hypermarkets, shops, sport halls, conference halls, poultry and cattle farms, greenhouses and other similar premises. The unit design enables quick and easy mounting and reduces total investment costs for heating (cooling) system.



THE UNIT IS NOT INTENDED TO BE USED BY CHILDREN, PHYSICALLY OR MENTALLY DISABLED PERSONS, PERSONS WITH SENSORY DISORDER, PERSONS WITH NO APPROPRIATE QUALIFICATION.

ANY OPERATIONS WITH THE UNIT MUST BE PERFORMED ONLY BY PROPERLY QUALIFIED PERSONNEL AFTER THE APPROPRIATE SAFETY BRIEFING.

THE UNIT INSTALLATION SITES MUST PREVENT ACCESS BY UNATTENDED CHILDREN.

DELIVERY SET

- AOW unit - 1 item
- user's manual - 1 item
- packing box - 1 item
- drain pipe - 1 item (applicable for AOW 25, AOW 30, AOW 45)

DESIGNATION KEY

AOW x XX

Unit type

AOW - air heating (cooling) unit

Modification

_ - model used both for cooling and heating

1 - model used for heating only

Heater power [kW]

TECHNICAL DATA

The unit is designed for indoor application with the ambient temperature ranging from +1 °C up to +50 °C.

The maximum permissible water temperature at 100 °C is 1.6 Map (16 bar). The unit is designed for application in moderate and cold climate conditions.

The water is supplied to the water-to-air heat exchanger via a double-pipe system.

The water supplied to the water-to-air heat exchanger has low temperature in the warm season and high temperature during heating.

The unit design is regularly being improved, so some models can slightly differ from those ones described in this manual.

Technical data:

Parameters	AOW 25 AOW1 25	AOW 30 AOW1 30	AOW 45 AOW1 45
Voltage, 50 Hz [V]	230	230	230
Fan power [W]	136	191	255
Fan current [A]	0,6	0,85	1,12
Rotation speed [min ⁻¹]	1350	1440	1360
Noise level, 3 m [dB(A)]	53	55	58
Maximum heat medium temperature [°C]	100	100	100
Ingress Protection Rating	IP 44	IP 44	IP 44
Insulation class	F	B	F
Air throw [m]	9	12	16

Technical data for heating mode:


Model	Air flow [m³/h]	Inlet air temperature [°C]	Temperature difference 90/70 °C				Temperature difference 80/60 °C				Temperature difference 70/50 °C				Temperature difference 60/40 °C			
			Power [kW]	Inlet temperature [°C]	Water flow [l/s]	Water pressure loss [kPa]	Power [kW]	Inlet temperature [°C]	Water flow [l/s]	Water pressure loss [kPa]	Power [kW]	Inlet temperature [°C]	Water flow [l/s]	Water pressure loss [kPa]	Power [kW]	Inlet temperature [°C]	Water flow [l/s]	Water pressure loss [kPa]
AOW 25 AOW1 25	2200	-15	34,5	26,0	1,5	7,5	30,4	21,2	1,3	6,0	26,0	16,0	1,1	4,6	22,0	11,0	1,0	3,4
		-10	32,0	29,0	1,4	6,6	28,3	24,3	1,2	5,3	24,0	19,2	1,1	4,0	20,0	14,0	0,9	2,8
		-5	30,0	32,0	1,3	5,8	26,2	27,4	1,2	4,6	22,0	22,0	1,0	3,4	18,0	17,0	0,8	2,3
		0	28,0	35,0	1,2	5,2	24,1	30,4	1,1	4,0	20,0	25,0	0,9	2,8	16,0	20,0	0,7	1,8
		5	26,2	38,5	1,2	4,5	22,1	33,3	1,0	3,3	18,0	28,0	0,8	2,3	14,0	22,0	0,6	1,4
		10	24,2	41,4	1,1	3,9	20,1	36,1	0,9	2,8	15,9	30,6	0,7	1,9	12,0	25,0	0,5	1,0
		15	22,1	44,2	1,0	3,3	18,1	38,8	0,9	2,3	13,8	33,0	0,6	1,4	9,0	27,0	0,4	0,7
AOW 30 AOW1 30	3000	-15	48,4	27,2	2,1	7,4	42,0	22,0	1,9	6,0	36,6	17,0	1,6	4,7	31,0	11,7	1,3	3,5
		-10	45,4	30,3	2,0	6,6	39,0	25,2	1,7	5,3	33,7	20,0	1,5	4,0	27,6	14,6	1,2	2,9
		-5	42,4	33,4	1,9	5,9	36,7	28,2	1,6	4,6	30,0	22,9	1,4	3,4	24,0	17,4	1,1	2,4
		0	39,5	36,4	1,7	5,2	33,8	31,1	1,5	3,9	28,0	25,7	1,2	2,9	21,0	20,0	1,0	1,9
		5	36,7	39,4	1,6	4,5	30,9	34,0	1,4	3,4	25,0	28,5	1,1	2,4	19,0	22,7	0,8	1,5
		10	33,8	42,1	1,5	3,9	28,1	36,7	1,2	2,8	22,0	31,1	1,0	1,9	16,0	25,2	0,7	1,1
		15	31,0	44,9	1,4	3,3	25,3	40,0	1,1	2,3	19,4	33,7	0,9	1,5	13,0	27,5	0,6	0,7
AOW 45 AOW1 45	3850	-15	63,0	28,4	2,8	11,9	55,6	23,3	2,4	9,7	48,1	18,1	2,1	7,6	40,4	12,8	1,8	5,7
		-10	59,2	31,5	2,6	10,6	51,8	26,4	2,3	8,5	44,3	21,1	1,9	6,6	36,7	15,7	1,6	4,8
		-5	55,4	34,6	2,4	9,4	48,0	29,3	2,1	7,4	40,6	23,9	1,8	5,6	32,9	18,5	1,4	3,9
		0	51,6	37,5	2,3	8,3	44,3	32,2	2,0	6,4	36,9	26,8	1,6	4,7	29,2	21,3	1,3	3,2
		5	47,9	40,4	2,1	7,3	40,6	35,0	1,8	5,5	33,2	29,5	1,5	3,9	25,6	23,9	1,1	2,5
		10	44,3	43,2	2,0	6,3	37,0	37,8	1,6	4,6	29,6	32,2	1,3	3,2	21,9	26,4	1,0	1,9
		15	40,6	45,9	1,8	5,4	33,4	40,4	1,5	3,8	26,0	34,8	1,1	2,5	18,1	28,8	0,8	1,3

Technical data for cooling mode:


Model	Air flow [m³/h]	Inlet air temperature [°C]	Temperature difference 7/12 °C			
			Power [kW]	Inlet temperature [°C]	Water flow [l/s]	Water pressure loss [kPa]
AOW 25	2200	35	9,1	26,0	1,6	7,5
		30	5,8	22,5	1,0	6,1
		25	3,2	21,0	0,6	2,1
		20	2,0	18,0	0,3	0,9
AOW 30	3000	35	11,4	27,0	2,0	11,2
		30	7,3	22,9	1,3	5,0
		25	3,9	21,1	0,7	1,6
		20	2,4	17,7	0,4	0,7
AOW 45	3850	35	18,0	24,9	3,1	31,8
		30	10,8	21,7	1,9	12,9
		25	7,3	19,0	1,3	6,3
		20	3,2	17,4	0,5	1,4

Note: AOW1 model is designed for operation in heating mode only. The unit has no components for condensate drainage.

- 1 - water-to-air heat exchanger
- 2 - axial fan with a protecting grille
- 3 - unit casing
- 4 - louvre shutters
- 5 - terminal box
- 6 - pipes of the water-to-air heat exchanger

AOW**Overall dimensions:**

Model	Dimensions [mm]							Number of coil rows	Weight [kg]
	B	B1	H	H1	L	L1	K		
AOW 25	680	785	605	468	360	286	G 3/4"	2	37,0
AOW 30	680	785	655	518	360	286	G 3/4"	2	40,0
AOW 45	780	885	710	570	380	300	G 3/4"	2	50,0

AOW1**Overall dimensions:**

Model	Dimensions [mm]							Number of coil rows	Weight [kg]
	B	B1	H	H1	L	L1	K		
AOW1 25	630	690	555	468	320	262	G 3/4"	2	28,0
AOW1 30	630	690	605	518	355	262	G 3/4"	2	31,0
AOW1 45	730	790	655	570	380	285	G 3/4"	2	41,0

DESIGN AND OPERATION LOGIC

The AOW unit consists of four basic components (refer fig. 1): a water-to-air heat exchanger (1), an axial fan with a protecting grille (2), a polymer coated steel casing (3), louvre shutters (4). The water-to-air heat exchanger is made of copper tubing ribbed with aluminium. The water-to-air heat exchanger is equipped with internally threaded (3/4) copper tubes.

An axial fan located at the unit inlet generates air flow in the water-to-air heat exchanger.

The protecting grille of the fan prevents foreign objects ingress inside the unit. The adjustable louvre shutters are located on the air supply side.

Each louvre vane is manually adjustable which makes it easy to create a required air stream direction. The curved profile of the louvre vanes prevents air flow turbulence and its rising toward upper part of the room thus keeping warm air within the heated area.

The unit operation is based on heat/cool conduction from the hot or cold water to surface of the copper tubes filled with circulating water. The copper tubes have aluminium fins for extra large heat exchange surface.

The copper tubes transfer heat energy to the aluminium fins and the fins transfer it further to the air flow generated by the fan. The heated (cooled) air flow is supplied to the premises and directed locally by means of the louvre shutters.

The AOW model is a single-room air heating / cooling system and the AOW1 model is a single-room air heating system.

The unit is suitable both for vertical and horizontal installation.


During operation of the unit in the cooling mode some condensate may appear on the surface of the heat exchanging surface and get accumulated in the unit drain pan.

The AOW 25, AOW 30 and AOW 45 units must be equipped with a drain pipe. Fix the drain pipe to the unit bottom with rivets.


The drain pipe and the rivets are supplied with the air heating (cooling) unit.

Installation of the drain pipe:



The drain pipe opening is plugged.



Remove the plug.



Apply some sealant on the mating surfaces of the pipe and drain pan mating surfaces. Fix the pipe with fasteners.



The unit is designed for indoor installation in compliance with applicable hygienic norms and standards.

MOUNTING AND SET-UP

Provide free air access to the fan intake vent while installing the unit. The minimum distance between the wall or ceiling and the AOW unit is 300 mm. The unit mounting location must provide free service access to the unit.

The unit is designed for wall mounting or any other vertical installation as well as ceiling mounting using the fixing brackets.

While connecting the water-to-air heat exchanger to the water main disable any loads that can damage the unit or tight connections.

Layout of the heat medium piping must ensure quick detachment for easy servicing and repair operations. Install a mud filter at the heat medium inlet to the heat exchanger.



THE UNIT INSTALLATION SHALL ONLY BE PERFORMED BY PROFESSIONALS AFTER CAREFUL STUDY OF THE PRESENT USER'S MANUAL.



WARNING!
FAILURE TO PROVIDE MINIMUM DISTANCE TO WALLS OR CEILING WILL IMPAIR THE UNIT AERODYNAMIC AND THERMAL PROPERTIES AND SERVICE LIFE OF THE UNIT.


Mounting accessories:

Model	Mounting angles	Mounting bracket	Multi-angle bracket
AOW 25	MKP-AOW	MK-AOW 25	MKY-AOW 25
AOW 30	MKP-AOW	MK-AOW 30	MKY-AOW 30
AOW 45	MKP-AOW	MK-AOW 45	MKY-AOW 45
AOW1 25	MKP-AOW	MK-AOW1 25	MKY-AOW1 25
AOW1 30	MKP-AOW	MK-AOW 25*	MKY-AOW 25
AOW1 45	MKP-AOW	MK-AOW 30*	MKY-AOW 30



* The cross pieces between the MK-AOW mounting brackets are not applicable in case of AOW1 mounting.

INSTALLATION OF THE UNIT WITH MKP-AOW MOUNTING SET

The MKP-AOW mounting set is used for ceiling mounting of the unit by means of the mounting studs or chains. Not included in the delivery set, available as a special accessory.




INSTALLATION OF THE UNIT WITH MKP-AOW**INSTALLATION OF THE UNIT WITH MKP-AOW MOUNTING BRACKET**

The MK-AOW mounting bracket is used for ceiling or wall mounting of the unit. Not included in the delivery set, available as a special accessory.

CEILING MOUNTING WITH MK-AOW**WALL MOUNTING WITH MK-AOW****INSTALLATION OF THE UNIT WITH MKU-AOW MULTI-ANGLE BRACKET**

The MKU-AOW mounting multi-angle bracket is used for ceiling or wall mounting of the unit. Not included in the delivery set, available as a special accessory.

MKU-AOW design enables installation of the unit to the wall or ceiling and fixation at 30° and 45°.


RIGHT ANGLE MOUNTING WITH MKU-AOW**30° MOUNTING WITH MKU-AOW****45° MOUNTING WITH MKU-AOW**

UNIT REACH DISTANCE

Failure to provide the minimum distance to walls or ceiling 0.3 m will impair the unit aerodynamic and thermal properties and service life of the unit.


Wall mounting:

Minimum distance to the wall is 0.3 m
Mounting height is 3 to 8 m
Max. air throw is 16 m



Ceiling mounting:

Minimum distance to the ceiling is 0.3 m
Mounting height is 4 to 14 m



WIRING DIAGRAM



DISCONNECT THE UNIT FROM POWER MAINS PRIOR TO ANY ELECTRIC INSTALLATION OPERATIONS. THE UNIT ELECTRICAL INSTALLATION SHALL ONLY BE PERFORMED BY A PROFESSIONAL ELECTRICIAN. THE RATED ELECTRICAL PARAMETERS OF THE UNIT ARE STATED ON THE RATING PLATE. ANY TAMPERING WITH THE INTERNAL CONNECTIONS IS PROHIBITED AND WILL VOID THE WARRANTY.

The unit is rated for connection to single-phase ac 220-230 V / 50 Hz power mains.

For unit electric connections use insulated, durable and heat-resistant cables and wires with a cross section not below 0.5 mm².

The wire sections as stated are for reference only! The actual selection should be made in consideration of the maximum wire temperature depending on the wire and insulation type, the maximum current, the lead wire length and its installation (suspended, duct-mounted or wall-mounted).

Connect the unit to power mains through the terminal block located inside the terminal box in compliance with the wiring diagram and the terminal designation.


The automatic circuit breaker with thermomagnetic release (automatic switch) must be installed at the input to break all the circuits.

The circuit breaker QF must be installed in such a way as to provide a free access for quick shutdown of the unit.

The trip current must be in compliance with the current consumption of the unit. The rated recommended current of the switch is 1.6 A.

The unit is equipped with AC external rotor motors with self-resetting integrated overheating protection.

WIRING DIAGRAM



CONTROL AND ADJUSTMENT

Smooth or step fan speed control is performed by means of a thyristor or transformer speed controller. Reducing the fan speed enables to reduce air flow and heating or cooling heat exchange.

The air heating (cooling) unit is operated via the UWT-1E control unit (special accessory). The control unit has three operation modes and three fan speed stages for AOW.

The control unit is equipped with an on/off switch with a control lamp, cable glands for cable connections and a thermal fuse for short circuit protection.


The control unit is designed for joint operation with the TST-1-300 digital thermostats with sensor display (TSTD-1-300 is available with a remote control) or RTS-1-400 with a LCD display (RTSD-1-400 is available with a remote control). The thermostats are available as special accessories. The thermostat must be installed in a premise that is heated or cooled by the AOW unit. The thermostat is used for air temperature monitoring and operation mode control.

The thermostat installation place must not be subjected to temperature fluctuations induced by open windows, door and heating devices. Several air heating (cooling) units installed in the same premise may share one thermostat.

MAINTENANCE

Regular routine maintenance operations are recommended. The aluminium ribs must be cleaned of dirt and dust once a year with a wet cloth or a vacuum cleaner. In case of high hygienic condition in the premises clean the fins as required.

Disconnect the unit from power mains prior to any maintenance operations.



TROUBLESHOOTING

Possible faults and troubleshooting

Fault	Possible reasons	Fault handling
The fan does not start up during the unit start-up.	No power supply.	Make sure that the unit is properly connected to the power mains and troubleshoot a connection error, if necessary.
	Motor is jammed, the impeller are clogged.	Turn the unit off. Troubleshoot the motor jam and the impeller clogging. Clean the blades. Restart the unit.
Automatic switch tripping following the unit turning on.	Overcurrent resulted from short circuit in the electric circuit.	Turn the unit off. Contact the unit Seller.
Low air flow.	Low set fan speed.	Set higher speed.
	Control system malfunction.	Turn the unit off. Contact the unit Seller.
Heater malfunction.	Control system malfunction.	Turn the unit off. Contact the unit Seller.
High noise, vibration.	The impeller is soiled.	Clean the impeller blades.
	Loose screw connection of the unit fan or casing.	Tighten the screws of the fan or the casing against stop.

STORAGE AND TRANSPORTATION RULES

Transportation with any vehicle type is allowed provided that the unit is protected against mechanical and weather damage.

The unit shall be protected against weather and mechanical damages to preserve their functioning and appearance. Avoid any mechanical shocks and strokes during handling operations.

Store the AOW unit in the manufacturer's original packing box in a dry ventilated premise at the temperatures from +5°C up to + 40°C at relative humidity max. 80% at +25 °C.

Storage environment must not contain aggressive vapours and chemical mixtures provoking corrosion, insulation and sealing deformation.

MANUFACTURER'S WARRANTY

The manufacturer hereby warrants normal operation of the unit over the period of 24 months from the retail sale date provided the user's observance of the transportation, storage, installation and operation regulations.

Should any malfunctions occur during the unit operation through the manufacturer's fault during the warranty period the user is entitled to elimination of faults by means of warranty repair performed by the manufacturer.

The warranty repair includes work specific to elimination of faults in the unit operation to ensure its intended use by the user within the warranty period. The faults are eliminated by means of replacement or repair of the complete unit or the faulty part thereof.

The warranty repair does not include:

- Routine maintenance;
- Unit installation / dismantling;
- Unit setup.

To benefit from warranty repair the user must provide the unit, the user's manual with stamped sale date and the payment document certifying the purchase.

The unit model must comply with the one stated in the user's manual.

Contact the unit Seller for warranty service.**The manufacturer's warranty does not apply to the following cases:**

- User's failure to provide the unit with the entire delivery package as stated in the user's manual or with missing component parts previously dismounted by the user;
- Mismatch of the unit model and make with the respective details stated on the unit packing and in the user's manual;
- User's failure to ensure timely technical maintenance of the unit;
- External damage to the casing (excluding external modifications of the unit as required for its installation) and the internal components of the unit;
- Alteration of the unit design or engineering changes of the unit;
- Replacement and use of the unit assemblies, parts and components not approved by the manufacturer;
- Unit misuse;
- User's violation of the unit installation regulations;
- User's violation of the unit management regulations;
- Unit connection to the power mains with a voltage different from the one stated in the user's manual;
- Unit breakdown due to voltage surges in the power mains;
- User's discretionary repair of the unit;
- Unit repair performed by any persons without the manufacturer's authorization;
- Expiry of the unit warranty period;
- User's violation of the established regulations specific to the unit transportation;
- User's violation of the unit storage regulations;
- Wrongful acts against the unit committed by third persons;
- Unit breakdown due to circumstances of insuperable force (fire, flood, earthquake, war, hostilities of any kind, or blockade);
- Missing seals if provided by the user's manual;
- Failure to provide the user's manual with the sale date stamp;
- Missing payment document certifying the unit purchase.



FOLLOWING THE REGULATIONS STIPULATED HEREIN WILL ENSURE A LONG AND TROUBLE-FREE OPERATION OF THE UNIT.



USERS' CLAIMS SHALL BE SUBJECT TO REVIEW ONLY UPON PRESENTATION OF THE UNIT, THE PAYMENT DOCUMENT AND THE USER'S MANUAL WITH THE SALE DATE STAMP.

ACCEPTANCE CERTIFICATE


Product Type	Air heating (cooling) unit with water-to-air heat exchanger
Model	AOW _____
Serial Number	
Manufacturing Date	
is compliant with the technical specifications and is hereby declared ready for service.	
Quality Inspector's Stamp	

SELLER'S INFORMATION

Shop name	
Address	
Phone number	
E-mail	
Sales date	

This is to certify delivery of the complete unit with the user's manual. The warranty terms are acknowledged and accepted.

Customer's signature	
-----------------------------	--




Seller's seal

MOUNTING CERTIFICATE

The air heating (cooling) unit with water-to-air heat exchanger AOW ____ has been connected to power mains pursuant to the requirements stated in the present user's manual.

Company name		
Address		
Phone number		
Installation technician's full name		
Installation date:		Signature:




Installation technician's company seal

This is to certify that the work specific to the unit installation has been performed in accordance with all the applicable provisions of local and national construction, electrical and technical codes and standards. The unit operates normally as intended by the manufacturer.

Signature:	
-------------------	--

WARRANTY CARD

Product type	The air heating (cooling) unit with water-to-air heat exchanger
Model	AOW_____
Serial number	
Manufacturing date	
Sales date	
Warranty period	
Sales company	



Seller's seal





